



Spanish Galleon



Ship
INSTRUCTION SHEET

© PYRO PLASTICS CORP., 1968 PYRO PARK, UNION, NEW JERSEY MADE AND PRINTED IN U.S.A.

ASSEMBLY INSTRUCTIONS

SPANISH GALLEON

BRAME OR PLASTIC PAINTS YOU WILL END YOU CAN DO A BETTER JOSEMBLY OVER ANY MOST OF THE PARTS BEFORE ASSEMBLING. USE POLYSTYRENE CHAINT ONLY, AND ALLOW PAINTED AND CEMENTED PARTS TO DRY THOROUGHLY BEFORE HANDLING. APPLY CEMENT CAREFULLY AND AVOID GETTING CEMENT ON HANDS SO AS NOT TO MAR PLASTIC SUSPACES.



- 1. Coment Right (2) and Left (3) Hull Halves together.
- 2. Cement Deck (1) to Ribs on inside of
- 3. Cement Gangway (26) to Ribs on Deck as
- 4. Cement 2 Railings (27) to Dack.
- 5. Cement 2 Anchors (21) over Roiling at
- 6. Cement Bowsprit (8) to Hole in Deck. 7. Cement Outrigger (17) to Hole in Hull at
- 8. Cement Canopy Cover (16) to Railing at
- 9. Cement Fore Mast (5) to Hole in Fore
- 10. Cement Main Mast (4) to Main Deck.
- 11. Coment Mixxon Most (7) to Half Deck
- 12. Cement Bongventure Mast (6) to Poop
- 13. Cement Fore Mast Crows Nest (15) from Fore Mast. Repeat procedure for Main Mast with Main Mast Crows Nest



RIGGING: Use Nock sowing throad, following the illustration on box cover. The amount of core and time you spend on your ripging will pay off in a year

- 14. Cement Name Plate (19) to Display Stand (18)
- 15. Cement Completed Display Stand to underside of Ship.
- Cement Left Fore Mast Ratline (25) to Rib on outside of Hull at Bow and to un-derside of Fore Mast Crows Nest. Repeat for Right Side with Right Fore Mast Rat-
- 17. Cement Left Main Most Ratline (23) to Rib on outside of Hull at Stern and to underside of Main Mast Crows Nest. Repeat for Right Side with Right Main Most Rotline
- 18. Cement Sprit Sail (13) to Bowsprit,
- 19. Cement 4 Cannons (20) to each side of Half Deck with Muzzles protruding through Hole in Hull.
- 20. Coment Fore Sail (10) to Fore Most.
- 21. Cement Main Sail (9) to Main Mast. 22. Cement Mizzen Sail (12) to Mizzen
- 23. Coment Bonaventure Sail (11) to Bona-
- venture Mast.